



**PSB INDUSTRIES INC.**  
**General Air Division**  
**www.psbindustries.com**

1202 West 12th Street, Erie, PA, USA 16501  
Phone: (814) 453-3651

P.O. Box 1318, Erie, PA, USA 16512-1318  
Fax: (814) 454-3492

# OILSORBER

## INSTALLATION INSTRUCTIONS MODELS OL 12 THRU OL 36

**Parts:** The PSB Oilsorber is shipped as a single vessel with the following parts for customer installation:

- (1) two basket assemblies
- (2) four gaskets
- (3) initial charge of desiccant

**Installation:** Place a gasket on both sides of the basket ring. Install the bottom basket first, through the lower weld-neck flange nozzle, making sure that it extends upward into the vessel. Next, mate the customer supplied inlet piping flange to the Oilsorber inlet then install and tighten bolting hardware. Now fill desiccant through the outlet nozzle located at the top of the vessel.

Following the above procedure, install the remaining basket assembly (top of Oilsorber) and mount inlet piping.

Slowly pressurize the Oilsorber to operating condition and check for leaks.

**Maintenance:** Periodically inspect the desiccant for excessive oil contamination (4-6 weeks) and replace desiccant if required.

Frequency of replacement will depend on the amount of oil in the plant air system.

Desiccant fill and drain ports are provided so the Oilsorber vessel does not have to be disconnected from the plant air piping for servicing.